

## STANDARD SYSTEM

### CONDENSED APPLICATION STEPS FOR ISO-FLEX 750U

#### COATING SYSTEM MVT

<u>STEP</u>	<u>METHOD OF APPLICATION</u>	<u>COMPONENT</u>	<u>APPROX COVERAGE</u>
Preparation	Patch and repair where needed. Route cracks over 1/16". Shot blast concrete. Caulk cracks and joints.	880GB/881	
Detail Coat	A 4" wide detail strip of primer and base coat are applied over all cracks less than 1/16" wide, control joints and cold joints	Primer 750 3 mils dft	900 lf/gallon
		750 Base Coat 21 wet/20 dry	225 lf/gallon
Primer	Roll or Spray apply	Primer 750 Base and Cure mixed 1:1 by volume	300 sq. ft/gallon

Note: If the Primer sits uncoated beyond 24 hours or becomes contaminated during cure, re-prime with a mixture of 750 Primer and Methyl Acetate (1:1 by vol). Apply at 500 sq ft/gal. Proceed with 750 Base Coat when new primer becomes tacky.

Membrane or Base Coat	1/4" notched squeegee followed by back rolling with a 3/4" nap roller	750 Base Coat and Cure. (Mix only full matched units.) 27 wet/25 dry mils	60 sq ft/gallon
-----------------------------	--	--	-----------------

Note: If the 750 Base Coat becomes wet or contaminated after cure, it must be physically abraded and re-primed with a mixture of 750 Primer and Methyl Acetate (1:1 by vol ). Apply at 500 sq ft/gallon. Proceed with the wear course installation when the new primer becomes tacky.

Wear Course	1/4" notched squeegee followed by back rolling with a 1/2" - 3/4" nap roller	750 AR Top Coat 18 wet/15 dry mils	90 sq ft/gallon
	Carefully hand spread or blow aggregate uniformly into wet Top Coat. Back roll as above	16/30 mesh clean dry silica sand	6 - 8 lbs/100 sq ft

(\* If the coated surface is directly exposed to the sun, use 750 AL Top Coat)

**TOTAL MILS                      40 MILS**