

CONDENSED APPLICATION STEPS FOR ISO-FLEX 760 U-HL LOW ODOR

COATING SYSTEM MVT

<u>STEP</u>	<u>METHOD OF APPLICATION</u>	<u>COMPONENT</u>	<u>APPROX COVERAGE</u>
Preparation	Patch and repair where needed. Route cracks over 1/16". Shot blast concrete. Caulk joints and cracks.	880GB/881	
Detail Coat (Optional)	A 4" wide detail strip of primer and base coat are applied over all cracks less than 1/16" wide, control joints and cold joints	See primers below 750 Base Coat 21 wet/20 dry mils	240 lf/gallon
Primer	Roll or Spray apply	Primer Epoxy SF Primer 757 Low Odor Primer #20	200 sq. ft/gallon 300 sq. ft/gallon 300 sq. ft/gallon

Note: The Primers Epoxy SF and 757 must be totally dry before applying the 750 Base Coat. The maximum dry time for the Epoxy SF and 757 Primer is 24 hours. Low Odor Primer #20 dries in 1 hour.

Membrane or Base Coat	1/4" notched squeegee followed by back rolling with a 3/4" nap roller	750 Base Coat and Cure. (Mix only full matched units 27 wet/25 dry mils	60 sq ft/gallon
-----------------------	---	--	-----------------

Note: If the 750 Base Coat becomes wet or contaminated after cure, it must be physically abraded and re-primed with Low Odor Primer #20. Apply at 400 sq ft/gallon. Proceed with the wear course installation when the new primer becomes dry.

Wear Course	1/4" notched squeegee followed by back rolling with a 1/2" to 3/4" nap roller	760 IC Base and Cure (Mix only full matched units) 10 wet/10 dry mils	130 sq ft/gallon
	Carefully blow aggregate to excess into wet Intermediate Coat. When cured, remove excess aggregate.	16/30 mesh clean dry silica sand	1/2 lb/1 sq ft

Note: The Intermediate Coat seeded with aggregate will cure in 3-6 hours. The two component Lock Coat should be applied within 24 hours.

Lock Coat	1/8" notched squeegee followed by back rolling with a 1/2" to 3/4" nap roller	760 Lock Coat Base and Cure 12 wet/12 dry mils	110 sq ft/gallon
-----------	---	---	------------------

Note: The Lock Coat has a pot life of 30-45 minutes. As soon as the unit is mixed, the Lock Coat should be immediately poured onto the deck. If the mixed product is left in the pail, the pot life will decrease. The Lock Coat cures in 6-8 hours and can be turned over to light traffic in 24 to 36 hours.

TOTAL MILS 47 mils